

AUTOMATIC POOL COVERS NEW ENGLAND

RECESSED WOOD BOX

EXCAVATION:

Prior to setting a wood recessed box, make sure that the area where the box will be sitting is 16" below the deck height.

CALCULATING BOX LENGTH:

Take the track space (the inside measurement between the tracks plus 1"), then add 4". Example: (Space Between Tracks + 1") + 4" = Box Length

BOX SIZE REQUIREMENTS:

Track Length:	1' - 44'	45' - 55'	56' - 65'	66' +
Box Size:	13"	14"	15"	16"

- Standard mechanism ID is 10-1/4" to 14-1/4"
- Standard aluminum lid and hinge is 16-3/4" wide. A wide lid, 19", is available.
- Wider mechanism brackets will be needed for boxes wider than 14".
- APC's hybrid webbing will roll up larger than standard white Dacron webbing.

